













1




2








30 88 929


3



4











30 02 419




30 02 426






30 20 553



30 09 465



30 02 426




30 02 419






30 20 526



30 04 193




2x 30 02 426









30 20 526





1





2






3



4





Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

pronounce: plāy-mō-bēel